

DE Montageanleitung

EN Mounting instruction

ES Instrucciones de instalación

FR Instructions d'installation


IT Istruzioni per l'installazione

NL Montagehandleiding


CS Návod k instalaci

PL Instrukcja montażu

RU Инструкция по монтажу



59591 010001 59591 030001
 59591 050001 59591 070001
 59591 130001 59591 170001
 59591 370001



59591 010002 59591 030002
 59591 050002 59591 070002
 59591 130002 59591 170002
 59591 370002

DE Einbaumaße

FR Cotes de montage

CS Montážní rozměry

EN Mounting dimensions


IT Ingombro

PL Wymiary montażowe


ES Dimensiones de montaje

NL Montageafmetingen







RU Монтажные размеры



59591 XX0001



59591 XX0002



DE Ersatzteile

FR Pièces de rechange

CS Náhradní díly

EN Spare parts


IT Ricambi

PL Części zamienne

ES Piezas de recambio

NL Reserveonderdelen

RU Запчасти



XX = 01, 03, 05, 07, 13, 17, 37

